QUICK START

Range base station

SHOOMS Core · server and network

SHOOMS

QS-BS-EN · 09.2026

BEFORE YOU START

The mini-computer and the router go in a dry technical room: ingress protection IP20.

INSTALLATION STEPS

1. Install the mini-computer and the main router in the technical room.
2. Connect the mini-computer to the router with the supplied LAN cable.
3. Mount the outdoor access point and connect it to the router with a cable.
4. Connect the router to the customer's internet — for updates and remote support.
5. Switch on the router and the access point, then the mini-computer with its power button.
6. Wait for the server to start and check it from a laptop on the range network.
7. From here, SHOOMS support configures the network and binds the devices to the fields.

BEFORE YOU LEAVE

- [ ] Mini-computer and router in the technical room
- [ ] LAN cable between them connected
- [ ] Outdoor access point mounted and connected
- [ ] Customer's internet connected
- [ ] The server answers on the range network
- [ ] Ventilation openings not blocked
- [ ] Serial number recorded

IF SOMETHING DOES NOT WORK

The server does not answer	The mini-computer's power and its indicator; allow a few minutes to start
Devices do not see the network	The router's power and indicators
Devices at the edge of the range drop out	The outdoor access point, its cable and its orientation
Updates do not arrive	The router's connection to the customer's internet

The full user manual is in the documentation set or behind the QR code. SHOOMS support: support@shooms.net