QUICK START

Target release module

sp-rb_jrc · 16 channels

SHOOMS

QS-RB-EN · 09.2026

BEFORE YOU START

All work is done with the traps switched off and the system stopped. Only SHOOMS staff open the module's enclosure.

INSTALLATION STEPS

1. Fix the enclosure by its four mounting lugs on a wall or in a cabinet, in a dry place.
2. Connect the trap cables to channel connectors 1–16 according to the field layout. Tighten the coupling nuts fully.
3. Write down which trap is connected to which channel: you will need it for the check.
4. Connect the referee remote to the «СУДДЯ» connector.
5. Make sure the DEBUG button is released.
6. Connect the power supply to the «12V» connector, then plug it into a 230 V socket.
7. After 10–20 seconds the indicator should change to a slow blue blink: the module is on the range network.
8. Test the channels one by one from the server and compare with your record: exactly that trap must fire.
9. Test the referee remote: the large button releases a target.

BEFORE YOU LEAVE

- [ ] All 16 channels tested and matched against the record
- [ ] Referee remote tested
- [ ] Cables secured, connector nuts tightened
- [ ] DEBUG button released
- [ ] Indicator blinks blue
- [ ] Serial number recorded, passport filled in and handed to the customer

IF SOMETHING DOES NOT WORK

The module is not in the system	The module's power and the range router; the indicator should blink blue
A channel does not fire	The trap cable and the trap's own power; try the neighbouring channel
A different trap fires	The channels are swapped — compare with your record
The remote does not work	The «СУДДЯ» connector and the remote cable along its whole length

The full user manual is in the documentation set or behind the QR code. SHOOMS support: support@shooms.net