QUICK START

Wireless release receiver

sp-wr_mini · on the trap

SHOOMS

QS-WR-EN · 09.2026

BEFORE YOU START

All work is done with the trap unpowered. Only SHOOMS staff open the module's enclosure.

INSTALLATION STEPS

1. Fix the module's enclosure on the trap so that vibration does not reach the cable and connectors.
2. Screw the antenna fully onto the SMA connector and position it vertically.
3. Connect the trap's release circuit to the RELAY1 output.
4. Connect 12 V power: from the Promatic trap connector or from a separate converter.
5. Switch the power on. Ask the transmitter operator to send a test command.
6. Make sure it is exactly this trap that fires, and write its number in the installation log.

BEFORE YOU LEAVE

- [ ] Enclosure fixed firmly
- [ ] Antenna screwed fully on and vertical
- [ ] Release circuit connected to RELAY1
- [ ] 12 V power connected
- [ ] The test command fires exactly this trap
- [ ] Serial number recorded

IF SOMETHING DOES NOT WORK

The trap does not fire on any command	The module's power, the cable and the trap connector or converter
The trap does not fire, others do	The antenna: screwed on, vertical, not shielded by metal
A different trap fires	The trap numbers are swapped — check the installation log
Release is delayed or intermittent	The antenna position and the distance to the transmitter

The full user manual is in the documentation set or behind the QR code. SHOOMS support: support@shooms.net